


VÆKKEUR

MED TRÅDLØS OPLADNING OG UV STERILISATION




Betjeningsvejledning

Tillykke med deres nye vækkeur med trådløs opladning og sterilisation af din mobil. Læs vejledningen omhyggeligt igennem for ibrugtagning og gem denne for senere brug.

1. Produktoversigt

Specifikationer:

Input (type C)	: 5V/2A, 9V/1.67A
Trådløst output	: 5W/7.5W/10W(Max)
USB-Output	: 5V1A ± 5% - 5V2A ± 5% (maks.)
Display lysstyrke	: 3 niveauer
Tidssystem	: 12/24 timer.
Oplade effektivitet	: CA. 73%
Trådløs transmission	: <8mm afstand
Lys	: UV-lys
Størrelse	: 143X 109X120 mm
Vægt	: 250g



2. Sådan anvendes produktet

Strømforsyning

Sæt USB opladerkablet i en adapter til 230V (medfølger ikke) og sæt Type C-porten i produktet. Adapteren sættes i dit stik på væggen.

Hvordan anvender jeg den trådløse oplader:

- Når strømmen tilsluttes blinker lade lyset et par gange og går i stand by tilstand. Derefter slukker lade lyset. (lade lyset er placeret på fronten af produktet)
- Mobiltelefonen placeres i lade området og lade lyset tænder. For Android mobil slukker lyset når mobilen er fuldt opladet.
- FOD-status : (Foreign Object Detection) lade lyset blinker konstant, hvis der er et metal fremmed legeme på/i lade området.

Indstilling af 12 eller 24 timers format:

Dobbeltklik på "M"- knappen for at skifte mellem 12-timers og 24-timers format. 12-timers formatet har AM- og PM-visning

Indstilling af vækkeur og klokken:

- Tryk på og hold "M"-knapen nede for at indstille henholdsvis alarm 1 og alarm 2.
- Tryk på og hold "M"-knapen nede i 2 sekunder for at indstille alarm 1, når tiden på displayet begynder at blinke, skal du trykke på +/- knappen for at indstille minutterne, tryk derefter på "M" knappen for at skifte til indstilling af timerne på alarm 1. Hvis der ikke er yderligere drift i 5 sekunder, vil indstillingerne blive gemt automatisk. Du kan også kort trykke på alarmknappen (lys knappen) for at gemme indstillingerne.
- Tryk på og hold "M"-knapen nede i 2 sekunder to gange for at indstille alarm 2, når tiden på skærmen begynder at blinke, skal du trykke på +/- knappen, for at indstille minutterne på alarm 2.

Tryk derefter på "M"-knapen for at skifte til indstilling af timerne på alarm 2. Hvis der ikke udføres yderligere handlinger inden for 5 sekunder, gemmes indstillingerne.

- Til sidst, tryk og hold "M"-knapen nede i 2 sekunder tre gange for at indstille klokkeslættet. Tryk på +/- knappen for at indstille minutterne, tryk på "M" knappen for at skifte til indstilling timerne. Hvis der ikke udføres yderligere handling inden for 5 sekunder, gemmes indstillingerne.

Slå alarm til/fra:

- Tryk på lys (ALARM) knappen og hold den nede for at tænde alarm 1, og tryk og hold lys (ALARM)-knapen nede indtil alarm 1 slår fra.
- Tryk på lys (ALARM) knappen to gange for at tænde alarmen 2, og tryk og hold lys (ALARM) knappen nede for at slå alarm 2 fra.
- Når vækkeuret (alarmen) ringer, tryk på en vilkårlig knap, for at afbryde alarmen.
- Alarmen ringer i 30 sekunder, og stopper derefter i 10 sekunder. Dette gentages 2 gange.
- Når vækkeuret ringer, skal du trykke på produktet (ikke på knapperne) for at komme i snooze-tilstand, det vil ringe igen efter 5 minutter. Dette gentages 3 gange. (Enhver tryk under Snooze tilstand vil slukke Snooze tilstand, og vækkeurets indikator lys vil stoppe med at blinke. Der er kun én Snooze tilstands chance for hver alarm. Når uret er i Snooze-tilstand, blinker ur indikatoren, og ved at trykke på en vilkårlig knap kan Snooze-tilstanden afsluttes.

Indstilling af skærmens lysstyrke:

- Skærmens lysstyrke har 4 niveauer: Kraftig / Mellem / Svag / slået fra. Lysstyrken ændrer sig periodisk: fra kl. 7:00 -19:00 kraftigt lysstyrke, fra 19:00 til 00 mellem lys styrke, fra 00 til 7:00 svag lys styrke
- Du kan også justere lysstyrken ved kort at trykke på "+/-" knappen

Tid hukommelse:

- Fjern det lille plast ark fra knapcellebatteriet, før du bruger produktet. Herved får du hukommelse/ huskes de indlagte tider. (knapcellebatteri medfølger)
- Knappcellebatteriet har kun til formål at huske klokkeslættet, når produktet ikke får tilført strøm.
- For at fastholde indtastede tider m.m. skal der være tilsluttet strøm til produktet.
- Når knapcellebatteriet er opbrugt, skal det udskiftes. Dette for at sikre, at huske funktion stadig fungerer. Tryk ned på dækslet og træk det derefter ud for at udskifte knapcellebatteriet.

Desinfektionscyklus:

Et enkelt tryk på lys knappen = 15 minutter desinfektion, (Slukkes automatisk efter 15 minutter). Dobbelttryk på lys knappen = 20 minutter desinfektion. (Slukkes automatisk efter 20 minutter). Tre tryk på lys knappen = der slukkes for desinfektion.

3. Kompatibilitet:

Trådløs opladningsflade til:

iPhone X/8/8plus, Samsung Galaxy Note 8, S8/S8 Plus, S7/S7 Edge, S6 Edge Plus,

Note 5 og andre Qi-enheder.

BEMÆRK: Hvis din mobil ikke understøtter Qi-standarder, skal du købe en ekstra trådløs modtager, for at kunne anvende den trådløse opladning via vækkeuret.

For at sikre hurtig trådløst opladning på 10 W er det nødvendigt, at bruge en QC3.0 adapter. Andre adapterer kan godt anvendes, men så tager opladningen længere tid.

4. Vær opmærksom på følgende:

- Brug ikke det trådløse vækkeur/oplader i nærheden af vand. Rengør produktet. Herved får du hukommelse/ huskes de indlagte tider. (knapcellebatteri medfølger)
- Brug ikke det trådløse vækkeur/oplader på fugtige overflader.
- Udsæt ikke produktet for kraftig varme eller ild.
- Tryk altid forsigtigt på alle knapper eller kontakter.
- Anvend ikke produktet i ekstrem tørre miljøer, da dette kan føre til statisk afladning under brug.
- Udsæt ikke produktet for temperaturer over 45°C eller under 0°C. Eller placering i direkte sollys.
- Forsøg ikke selv at reparere produktet. Herved bortfalder al garanti.
- Hold afstand mellem implanteret medicinske udstyr (pacemaker m.m.) og produktet > 20 CM for at undgå potentiel interferens med det medicinske udstyr.

BEMÆRK: Billederne i manualen er skematiske tegninger, og det endelige produkt kan afvige.

VIGTIGE SIKKERHEDSINSTRUKTIONER

Denne enhed er designet og konstrueret således, at hvis den anvendes korrekt, så har du et godt og sikkert produkt i årene. Forkert brug kan dog resultere i potentielle elektriske stød- eller brandfare. Læs alle sikkerheds- og betjeningsvejledninger omhyggeligt før installation og brug. Sørg for, at disse instruktioner er tilgængelige for senere brug.


Vær opmærksom på alle advarsler, der er anført i denne vejledning og på enheden.

- Vand og fugt - Enheden må ikke anvendes i nærheden af vand. F.eks.: i nærheden af en badekar, køkkenvask, vaskbæjle, eller i andre fugtige omgivelser.
- Ventilation - Enheden skal være placeret således, at der er god ventilation til produktet. For eksempel bør det ikke placeres på en seng, sofa, tæppe eller lignende overflade, der kan blokere ventilationsåbninger.
- Varme- Enheden skal være placeret væk fra varmekilder såsom radiatorer, ovne eller andre apparater (herunder forstærkere), der producerer varme.
- Strømkilder - Enheden må kun tilsluttes en strømforsyning af den type beskrevet i betjeningsvejledningen eller som markeret på produktet.
- Strøm-Kabel - Strømforsyning kablet bør placeres så de ikke bliver trådt på eller klemt.
- Rengøring - Produktet må kun rengøres med varm, fugtig klud. Brug ikke opløsningsmidler.
- Service/udbedning af skader - Enheden skal serviceres af kvalificeret service personale når:
 - Strømforsyningskablet eller stikket er blevet beskadiget.
 - Der er kommet fugt i produktet.
 - Produktet er blevet tabt eller kabinettet beskadiget.
 - Produktet udviser en markant ændring i ydeevne eller ikke fungerer normalt.

BEMÆRK: Skader forårsaget af fysiske stød, vand, væsker eller varme m.m. forårsaget af forkert brug er ikke dækket af garantien. Kun produktets design, funktion og funktionalitetens relaterede fejl vil blive overvejet.

ALARM CLOCK

WITH WIRELESS CHARGING




User Manual

Thanks for choosing us. Please read the product parameter list carefully below. The amazing user experience will make you love it.

1. Product overview

SPECIFICATIONS :

Input (Type-C)	: 5V/2A, 9V/1.67A
Wireless Output	: 5W/7.5W/10W(Max)
USB Output	: 5V1A ± 5% - 5V2A ± 5% (Max)
Display Brightness	: 3 Levels
Time System	: 12/24 Hrs.
Charging Efficiency	: Around 73%
Wireless Transmission	: <8mm Distance
Light	: UV Light
Size	: 143X 109X 120 mm
Weight	: 250g



2. How to use

Power Supply Steps

Plug the charging cable USB-A male into the power adapter (the power adapter needs to be plugged into the mains socket), and insert the Type-C port into the product.

Step of Using Wireless Charger:

- At the time of power-on, the wireless charging light shows the state: flashes twice; Standby state: The light is off.
- The mobile phone should be placed on the induction area, and the charging state is: indicator light is on; the full state is no light (applicable to Android mobile phone).
- FOD status : Indicator light keeps flashing.

Time Mode Setting:

Double-click the "M" button to switch between the 12-hour and 24-hour system; the 12-hour system has AM and PM display

Alarm Clock & Time Setting :

- Press and hold the "M" button to set alarm clock 1 and alarm 2 respectively.
- Press and hold the "M" button for 2 seconds to set the alarm 1, when the time on the display screen start flashing, press the +/- button to set the minute of the alarm clock 1, then short press "M" button to switch to set the hour of the alarm clock 1. If no further operation within 5 seconds, the settings will be saved. You could also short press the alarm button to save the settings.
- Press and hold the "M" button for 2 seconds twice to set the alarm clock 2, when the time on the display screen start flashing, press the +/- button to set the minute of the alarm clock 2, then short press "M" button to switch to set the hour of the alarm clock 2.

If no further operation within 5 seconds, the settings will be saved.

- Finally press and hold the "M" button for 2 seconds thrice to set the time of the clock. Press the +/- button to set the minute of the clock, then short press "M" button to switch to set the hour of the clock. If no further operation within 5 seconds, the settings will be saved.

Turn on/off the Alarm Clock :

- Press and hold the LIGHT (ALARM) button to turn on the alarm 1, long press the LIGHT (ALARM) button to turn off the alarm 1.
- Press and hold the LIGHT (ALARM) button twice to turn on the alarm 2, long press the LIGHT (ALARM) button to turn off the alarm 2.
- When the alarm clock rings, pressing any button can turn it off.
- Ring mode: The alarm clock rings for 30 seconds, then stop for 10 seconds, repeat this circulations for 2 times.
- When the alarm clock rings, tap the product to enter a snooze mode, it will ring again after 5 minutes for 3 times. (Any tap during the snooze mode will turn off the snooze mode, and the alarm clock indicator light stop flashing and it will not ring again.) It has only one snooze mode chance for each alarm. When it's in the snooze mode, the alarm clock indicator flashes, and by pressing any button could exit snooze mode.

Display Screen Brightness Setting :

- The light brightness of the display screen has 4 levels: Strong / Medium / Weak / Off. It changes periodically: AM7:00-PM7:00---Strong; PM7:00-AM0:00---Medium; AM0:00-AM6:00---Weak
- You could also adjust the brightness by short pressing the "+/-" button

Time Memory :

- Please remove the isolating sheet from the button cell before using the product to have the time memory function start working.
- The button cell battery is for memorizing the time of the clock only, when the product is out of power supply suddenly.
- To keep all functions working please keep the product power on.
- When the button cell is running out of battery, to ensure time memorizing function please replace with a new button cell. Press the cap and then pull it out to replace a new one.

Disinfection cycle:

Single press light button for 15minutes disinfection cycle(Automatically turn off in 15 minutes). Double press light button for 20 minutes disinfection cycle(Automatically turn off in 20 minutes). Triple press light button to turn off disinfection.

3. Compatibility:

Wireless Charging Pad for:

iPhone X/8/8plus, Samsung Galaxy Note 8, S8/S8 Plus, S7/S7 Edge, S6 Edge Plus,

Note 5 and other Qi enabled devices.

NOTE: If your device does not support Qi-Standards, you need to buy additional wireless receiver to use.

To ensure fast charge 10W wireless output it's necessary to use a QC3.0 power adapter.

4. Attention:

- Do not use your alarm clock wireless charger near water. Clean using a soft cloth or paper towel.
- Do not place your alarm clock wireless charger on any wet surfaces.
- Do not allow children or the infirm to play with your alarm clock wireless charger without adult supervision.
- Do not expose your alarm clock wireless charger to excessive heat, flames or fire.
- Always press all buttons or switches carefully. Do not manhandle your alarm clock wireless charger.
- Do not use in extremely dry environments, as this can lead to static discharge during usage.
- Do not expose your alarm clock wireless charger to temperatures above 45°C or below 0°C. Keep out of direct sunlight.
- Do not attempt to repair this product yourself.
- Do not drop, puncture or expose your alarm clock wireless charger to excessive trauma.
- Unplug your alarm clock wireless charger during lightning storms.
- Keep the distance between the implanted medical device (cardiac pacemaker, implantable cochlea, etc.) and the alarm clock wireless charger > 20CM to avoid potential interference with the medical device.

NOTE: The pictures in the manual are schematic drawings, and the final product is subject to the actual product.

IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety.

However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

- Water and Moisture - The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
- Ventilation - The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, which may impede the flow of air through the ventilation openings.
- Heat- The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
- Power Sources - The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
- Power-Cable Protection - Power supply cables should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. It is always best to have a clear area from where the cable exits the unit to where its plugged into an AC socket.
- Cleaning - The unit should be cleaned only using a warm damp cloth. Do not use solvents, etc.
- Objects and Liquid Entry - Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.
- Attachments - Do not use attachments not recommended by the product manufacturer.

9. Overloading - Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

10. Damage Requiring Service - The unit should be serviced by qualified service

Personnel when:

- the power supply cable or plug has been damaged.
- objects have fallen into or liquid has been spilled into the enclosure.
- the unit has been exposed to rain.
- the unit has been dropped or the enclosure damaged.
- the unit exhibits a marked change in performance or does not operate normally.
- Periods of Nonuse - If the unit is to be left unused for an extended period of time, such as a month or longer, the power cable should be unplugged from the unit to prevent damage or corrosion.
- Service - The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to qualified service personnel.

NOTE: Any damage caused by physical impact, Water/liquid, fire etc caused by customer or nature shall not be covered under warranty. Only product design, feature and functionality related faults will be considered.